

WIFI QUICK SETUP GUIDE HUAWEI HG8145V5

SETTING UP YOUR ROUTER

FOLLOW THESE STEPS

Configure WLAN

1. Go to **Home Page**. Make your changes under **WiFi Setting**.
2. Configure the SSID and password for 2.4Ghz and 5Ghz WLAN respectively. By default the SSID and password for both bands are the same. If they use the same SSID and password, then **band steering** is enabled. This means that the STA (PC/Phone) can automatically roam between 2.4Ghz and 5Ghz seamlessly.

The screenshot displays the 'Wi-Fi Setting' interface. On the left, a navigation menu includes 'Home Page', 'One-Click Diagnosis', 'System Information', and 'Advanced'. The main content area shows 'Internet' and 'Wi-Fi configuration' status. Under 'Wi-Fi Setting', there are two sections: 'Enable 2.4G Network' and 'Enable 5G Network'. Both are set to 'ON'. The 'Wi-Fi Name' for 2.4G is 'HUAWEI-2.4G-854e' and for 5G is 'HUAWEI-5G-854e'. The 'Password' fields are masked with asterisks. A 'Hide' checkbox is checked for both. At the bottom, there are 'Save' and 'Cancel' buttons.

Key in new
SSID & password

Key in new
SSID & password

**YOU GET THE ROCKET.
WE DO THE SCIENCE.**