



WIFI CONFIGURATION USER GUIDE

time™

TABLE OF CONTENTS


Turn On/Off WiFi	2
Change WiFi Name and Password	4
Hide WiFi Network	5
WiFi Scheduling	7

HOW TO NAVIGATE THE WIFI CONFIGURATION FEATURE IN THE TIME INTERNET APP


For Huawei devices (Huawei HG8145V5 and WA8021V5) only.

Turn On/Off Your WiFi


1. From the Control Hub screen, tap on **WiFi Configuration > WiFi Settings**.



2. Toggle on the **Turn On/Off WiFi** button to enable your WiFi. Your network is discoverable to all and devices can connect to it.




3. Toggle off the button to disable your entire WiFi network. All devices will be disconnected and your network cannot be accessed. **This action is not recommended.**




Change WiFi Name and Password

1. From the Control Hub screen, tap on **WiFi Configuration > Connected WiFi**.




2. Key in your new WiFi network name (SSID) and password. Tap **Save** to update.
*Please note that once you have saved your changes, the devices connected to your old SSID and password will be disconnected and you will have to connect again with the new credentials.




Hide WiFi Network


- 1. On the Control Hub screen, tap on **WiFi Configuration > WiFi Settings > Hide WiFi**.



- 2. Toggle on the **Hide WiFi** button to make your network undiscoverable to any device(s) not connected to your WiFi.






3. To make your network discoverable again, just toggle off the **Hide WiFi** button.



WiFi Scheduling

- 1. On the Control Hub screen, tap on **WiFi Configuration > WiFi Settings > WiFi Scheduling**.



2. Toggle on the **WiFi Scheduling** button to set a start and end time (24-hour format) for your WiFi to be turned on and accessible. For example, if you set your start time at 07:00 and end time at 23:00, that means that during the hours in between, your WiFi is turned on and devices can connect to it. After the scheduled time ends at 23:00, your WiFi will turn off and all devices will be disconnected from the network.

The image displays two side-by-side mobile app screens for configuring WiFi scheduling. Each screen has a grey header area and a white content area. The left screen is titled 'START AT' and features a time picker with the time set to 07:00. The right screen is titled 'CLOSE AT' and features a time picker with the time set to 23:00. Both screens have a pink 'CONFIRM' button at the bottom.

START AT

0 6 5 9

07:00

0 8 0 1

CONFIRM

CLOSE AT

2 2 5 9

23:00

0 0 0 1

CONFIRM

3. Toggle off the **WiFi Scheduling** button to keep your WiFi turned on at all times.